The Tallye™ Electronic Voting System

The voting system controller is used to enable and disable the voting process. This unit also enables the vote results to be displayed.

There is a voting station for each person that is allowed to vote. Each queuing/voting station has several buttons.

Voting Stations.

- The **NO** button.
- The **YES** button.
- The **ABSTAIN** button.

The voting process.

- To initiate the voting process, press the **Vote Enable** button on the voting system controller.

- The vote enable LED should begin blinking. Also, both the yes and no indicators on each of the voting stations will begin blinking.

- The count in the voting system controller display will be the number of persons that will be voting.

- Each of the voting members should select YES, NO or ABSTAIN.

- Once one of the vote buttons have been pressed, the indicators at that voting station will stop blinking and display the resulting vote on the indicators at that voting

station

- The vote may be changed at any time during the voting process until all persons have recorded their vote.

   Displaying the vote results.

Open vote.

The vote results may be displayed at any time during the voting process.

- Press and hold the **Vote Display** button. As voters make their selection, the results will be immediately displayed on the large wall display.
- Press the **Vote Preview** button to display the vote results on the local clerk's display.

Secret vote.

Display the vote results after the vote has been locked.

- Once everyone has voted, press the **Vote Enable** button to lock the vote into the

system.

- Press the **Vote Preview** button to display the vote results on the local clerk's display.

- Press and hold the **Vote Results** button to display the vote results on the large wall display.

- A detailed vote result will be displayed on the large vote results wall display.

- The most recent vote will be held in the system until a new vote is initiated.

- Once a new vote is initiated by pressing the **Vote Enable** button, the previous vote results are cleared.