

## Wall Jack Mounting Kit



### ***Contents:***

- One wall phone jack.
- One short RJ-11 phone cord.
- Two earthquake safety straps.
- Two 1-1/2 inch long wood screws.
- Two 4-40 short screws.
- Two 4-40 nuts

### ***Instructions:***

- Mount the wall phone jack onto a standard electrical box. Standard telephone wiring may be used for short distances. 18GA wire is recommended for longer distances.
- Attach one end of each of the earthquake safety straps to unused holes on the display using the 4-40 screws and nuts.
- Attach the other end of the earthquake safety straps to the wall. Be sure that the screws grab onto solid wood or metal. For greatest safety, do not attempt to use a single screw to hold both safety straps. Use a separate screw for each strap.
- Connect the short RJ-11 phone cord to the rear of the display.
- Connect the other end of the short RJ-11 phone cord to the wall phone jack.