

The TimeKeeper™ Count Up/Down Timer

Timer Mode (HH,MM,SS)

1. Press **Reset** to select timer mode.
2. Turn knob to set desired time. *The **Select** button selects between setting hours, minutes and seconds.*
3. Press the **Start/Stop** button to start the timer.

*The **Mode** button selects between count up and count down modes. You may change between count up and count down modes while the timer is running. In count down mode, the timer stops when it reaches zero. In count up mode, the timer keeps running when the preset time is reached.*

*Press and hold the **Mode** button to turn the beep on or off.*

*Press and hold the **Select** button to set the Wrap-It-Up time.*

*Turn the **knob** until the desired value appears.*

*Press the **Select** button again to set the Green warning time.*

*Turn the **knob** until the desired value appears.*

*Press the **Select** button again to return to normal display.*

The TimeKeeper™ Count Up/Down Timer

Red-Yellow-Green Display

- In the count down mode, the **Green** lamp comes on when the timer is started and begins to blink at the green warning time. In the count up mode, the **Green** lamp comes on at the green warning time..
- When the **Yellow** warning time is reached, the **Green** lamp goes off and the **Yellow** lamp comes on.
- When the timer reaches zero, the **Red** lamp comes on and the **Yellow** lamp goes off. In the count down mode, the timer stops when the **Red** lamp turns on. In the count up mode, the timer keeps running after the lamp turns **Red**.
- Press the reset button on the TimeKeeper™ to turn off the **Red** lamp.

Total time	Green warning	Yellow warning	Red warning
0:00 - 0:29	0:02	0:01	0:00
0:30 - 0:59	0:20	0:10	0:00
1:00 - 1:59	0:30	0:15	0:00
2:00 - 3:59	1:00	0:30	0:00
4:00-99:59	2:00	1:00	0:00

Alzatex, Inc. www.alzatex.com (503) 642-9693

The TimeKeeper™ Count Up/Down Timer

Timer Mode (HH,MM,SS)

1. Press **Reset** to select timer mode.
2. Turn knob to set desired time. *The **Select** button selects between setting hours, minutes and seconds.*
3. Press the **Start/Stop** button to start the timer.

*The **Mode** button selects between count up and count down modes. You may change between count up and count down modes while the timer is running. In count down mode, the timer stops when it reaches zero. In count up mode, the timer keeps running when the preset time is reached.*

*Press and hold the **Mode** button to turn the beep on or off.*

*Press and hold the **Select** button to set the Wrap-It-Up time.*

*Turn the **knob** until the desired value appears.*

*Press the **Select** button again to set the Green warning time.*

*Turn the **knob** until the desired value appears.*

*Press the **Select** button again to return to normal display.*

Alzatex, Inc. www.alzatex.com (503) 642-9693

The TimeKeeper™ Count Up/Down Timer

Red-Yellow-Green Display

- In the count down mode, the **Green** lamp comes on when the timer is started and begins to blink at the green warning time. In the count up mode, the **Green** lamp comes on at the green warning time.
- When the **Yellow** warning time is reached, the **Green** lamp goes off and the **Yellow** lamp comes on.
- When the timer reaches zero, the **Red** lamp comes on and the **Yellow** lamp goes off. In the count down mode, the timer stops when the **Red** lamp turns on. In the count up mode, the timer keeps running after the lamp turns **Red**.
- Press the reset button on the TimeKeeper™ to turn off the **Red** lamp.

Total time	Green warning	Yellow warning	Red warning
0:00 - 0:29	0:02	0:01	0:00
0:30 - 0:59	0:20	0:10	0:00
1:00 - 1:59	0:30	0:15	0:00
2:00 - 3:59	1:00	0:30	0:00
4:00-99:59	2:00	1:00	0:00

Alzatex, Inc. www.alzatex.com (503) 642-9693

Alzatex, Inc. www.alzatex.com (503) 642-9693