


# AOS and LOS Clock Reference Guide

Press the Set AOS button.  
The following display appears.



This displays some absolute time in the future when AOS is to happen.

Turn the knob to set day. (right 3 digits)

Press the Select button.

Turn the knob to set hour. (Left 2 digits)


Press the Select button.

Turn the knob to set minute.

Press the Select button.

Turn the knob to set second.

Press the Set LOS button.  
The following display appears.




Turn the knob to set minutes

Press the Select button.

Turn the knob to set seconds

Press the AOS/LOS Button.  
The following display appears.



The left 6 digits shows the time remaining in hours, minutes and seconds until AOS.


The right 4 digits shows the LOS.

Once the AOS is zero, the following display appears.



The LOS timer starts counting down in minutes and seconds.

If the AOS time entered is 4 days or greater,  
The hours digits will show dashes since  
the actual number of hours cannot be displayed.



If the AOS time is some time in the past, the  
AOS display will have dashes.



To calculate an AOS time at the end of the  
year, the number of seconds in a year  
needs to be known. 1 year = 31,556,926 seconds.

The start/stop button does not affect the AOS display.

The start/stop button starts or stops the LOS timer.  
The reset button resets the LOS timer to the last preset value.